
## **PowerWise Hardware Diagram**

inGate and inDAC





\* DC power terminals are interconnected. Do not connect to multiple power sources.